



## W30 : N-Type Wiring Kit

### Installation Instructions

#### Kit Contents:

N-type socket, pre-wired to side mounting plate  
Audible relay unit  
Snap Connectors

#### Installation:

Mount the pre-wired socket and mounting plate assembly between the towbar and towball. (On towing brackets already fitted with a socket mounting bracket, remove the mounting plate from the socket assembly, and bolt the socket body to the existing plate on the towbar). Feed the 7-core cable into the vehicle, through an existing hole/grommet if one exists, alternatively it may be necessary to drill an entry hole. Ensure any cable entry hole is sealed against water ingress after installation. Connect the wires from the 7-core cable as follows:

#### Connections:

Firstly, connect the audible relay to the 7-core cable and the car as follows:

Wire from Relay	Connect to:
Yellow	Yellow on 7 core cable
Green	Green on 7 core cable
White *	Earth on Vehicle Body
Orange	Left Direction Indicator in Vehicle Loom
Grey	Right Direction Indicator in Vehicle Loom

Next, connect the remaining wires in the socket's 7-core cable to the vehicle harness:

7-Core Cable	Connect to (Vehicle Harness)
Blue	Vehicle Foglight
White	Earth on Vehicle Body
Brown	Right-hand Tail Lamp
Red	Stop Light
Black	Left-hand Tail Lamp

*\* Note: Occasionally a relay may be supplied with a black or a pink wire in place of the white. In this case, either black or pink is taken to earth on the bodywork*